

LOGIC INSTRUMENT

an ARCHOS company

FIELDBOOK F57G2

Guide de Démarrage Rapide Quick Start Guide

V2.220804

FRANÇAIS

I. Contenu de la boîte

- ✓ Terminal durci Fieldbook F57G2
- ✓ Batterie
- ✓ Chargeur USB
- ✓ Câble USB Type C
- ✓ Guide de démarrage rapide

Remarque : *Le contenu de la boîte peut varier selon votre configuration*




II. Description du produit

AVERTISSEMENT

Votre Fieldbook F57G2 est protégé contre les infiltrations d'eau et de poussière et a été contrôlé suivant la norme IP67. Cette protection ne peut être garantie que lorsque le capot arrière est fermé et correctement verrouillé.


Assurez-vous de vous trouver dans un environnement sec et propre lorsque le capot arrière est ouvert.

Ce document est susceptible d'évoluer sans préavis.





III. Insérer la ou les cartes SIM et la carte mémoire

1. Retirez la batterie si celle-ci est déjà installée
2. Extrayez le support cartes
3. Insérez les cartes aux emplacements indiqués ci-dessous
4. Insérez le support cartes et poussez-le complètement



IV. Insérer ou remplacer la batterie

1. Installez la batterie dans le sens indiqué.
2. Placez le capot arrière puis glissez le verrou vers la position fermé (vers la droite).



ATTENTION

Avant de mettre en place le capot, assurez-vous que le verrou soit sur la position ouvert.

Assurez-vous que le capot soit en place et correctement verrouillé avant d'utiliser votre terminal Fieldbook F57G2.

Seules les batteries originales Logic Instrument pour Fieldbook F57G2 peuvent être utilisées avec cet appareil.

Assurez-vous d'être dans un environnement propre et sec lorsque le capot est ouvert.

N'insérez jamais une batterie détériorée, défectueuse, sale ou humide dans le terminal Fieldbook F57G2.

V. Démarrage et utilisation du bouton d'alimentation

Démarrage

Appuyez sur le bouton d'alimentation pour démarrer votre terminal

Arrêt et redémarrage

Appuyez longuement sur le bouton d'alimentation pour afficher les options permettant d'arrêter ou redémarrer le terminal

Verrouillage

Appuyez brièvement sur le bouton d'alimentation pour verrouiller le terminal et éteindre l'écran

Redémarrage forcé

Pour forcer le redémarrage du terminal, appuyez sur le bouton d'alimentation pendant 10 secondes

VI. Voyants

Voyant Système	Rouge fixe	Chargement en cours
	Vert fixe	Chargement terminé
	Rouge clignotant	Batterie faible
Voyant Scanner	Rouge	Code-barre capturé

VII. Indicateurs

Batterie		Batterie entièrement chargée
		Batterie chargée à moitié
		Chargement en cours
		Batterie faible
Modem		Signal fort
		Signal moyen
	RIEN	Pas de carte SIM
		Erreur carte SIM / Pas de service
Wifi		Wifi activé, aucun réseau connecté
		Wifi connecté
	RIEN	Wifi désactivé
NFC		NFC activé

VIII. Paramétrage des boutons

Pour changer l'affectation des boutons de votre terminal Fieldbook F57G2, suivez les instructions ci-dessous :

1. Allez dans Paramètres
2. Cliquez sur Remap Key
3. Cliquez sur Key Remap
4. Appuyez sur la touche que vous souhaitez paramétrer
5. Sélectionnez le type d'action que vous souhaitez attribuer à la touche :
 - a. KeyCode : pour émuler une touche clavier
 - b. Start Application : permet de sélectionner une application à exécuter lors de l'appui
 - c. Send Broadcast : Permet de paramétrer des broadcasts lors de l'appui et du relâchement de la touche.

IX. Paramétrage du scanner codes-barres

Vous pouvez configurer le scanner codes-barres intégré à votre terminal Fieldbook F57G2 via l'application Scanner ou en allant dans Paramètres / Scanner Settings

Vous avez également la possibilité de post traiter les codes scannés avec l'application ScanWedge ou en allant dans Paramètres / ScanWedge Profiles

X. Utilisation du système Android

Votre terminal fonctionne avec le système d'exploitation Android.

Pour toute aide ou information relative au système d'exploitation Android, vous pouvez consulter le service d'aide Google à l'adresse ***support.google.com/android***

XI. Nettoyer votre Fieldbook F57G2

Toujours débrancher votre Fieldbook F57G2 avant de le nettoyer.

Utilisez un chiffon doux humidifié avec de l'eau ou un détergent non alcalin pour essuyer l'extérieur du terminal.

Essayez délicatement l'écran avec un chiffon doux non pelucheux.

ENGLISH

I. Box contents

- ✓ Fieldbook F57G2 device
- ✓ Battery pack
- ✓ USB charger
- ✓ USB Type C cable
- ✓ Quick Start Guide

Note: *Box contents may vary depending on your configuration*




II. Product Description

WARNING

Your Fieldbook F57G2 is protected against water and dust ingress and has been tested to IP67 standard. This protection can only be guaranteed when the rear cover is closed and correctly locked.


Make sure you are in a dry and clean environment when the back cover is open.

This document is subject to change without notification.




III. Insert SIM card(s) and memory card

1. Remove the battery if it is already installed
2. Extract the card holder
3. Insert the cards in the slots shown below
4. Insert the card holder and push it completely



IV. Insert or replace the battery

1. Install the battery in the direction shown.
2. Place the back cover then slide the latch to the position CLOSE (to the right).



WARNING

Before placing the cover, make sure that the latch is in the position OPEN.

Make sure the cover is in place and properly closed before using your Fieldbook F57G2 device.

Never use a battery other than an original Logic Instrument Fieldbook F57G2 battery.

Make sure you are in a clean and dry environment when the back cover is open.

Never insert a damaged, defective, dirty or wet battery into the Fieldbook F57G2 device.

V. Starting up the device and using the power button

Start

Press the power button to start your device

Shutdown or restart

Long press the power button to display options to shut down or restart the device

Lock

Briefly press the power button to lock the device and turn off the screen.

Forced restart

To force restart the device, press the power button for 10 seconds

VI. LEDs

System LED	Steady red	Charging
	Steady green	Completely charged
	Flashing red	Low battery
Scanner LED	Red	Barcode scanned

VII. Indicators

Battery		Battery fully charged
		Battery half charged
		Battery Charging
		Low battery
Modem		strong signal
		Average signal
	NOTHING	No SIM card
		SIM card error / No service
Wireless		Wi-Fi enabled, no network connected
		Wi-Fi connected
	NOTHING	Wi-Fi disabled
NFC		NFC enabled

VIII. Keys Configuration

To change your Fieldbook F57G2 keys assignment, follow the instructions below:

1. Go to Settings
2. Click on Remap Key
3. Click on Key Remap
4. Press the key you want to configure
5. Select the type of action you want to assign to the key:
 - a. KeyCode: to emulate a keyboard key
 - b. Start Application: allows you to select an application to run when the key is pressed
 - c. Send Broadcast: Allows you to configure broadcasts when pressing and releasing the key.

IX. Barcode scanner setup

You can configure the barcode scanner integrated into your Fieldbook F57G2 device via the Scanner application or by going to Settings / Scanner Settings

You also have the option to post process scanned codes with the ScanWedge app or by going to Settings / ScanWedge Profiles

X. Using Android system

Your device works with Android operating system.

For any help or information related to Android operating system, you can consult the Google help service at ***support.google.com/android***

XI. Clean your Fieldbook F57G2

Always unplug the Fieldbook F57G2 before cleaning it.

Use a soft cloth dampened with water or a non-alkaline detergent to wipe the exterior of the device.

Gently wipe the screen with a soft, lint-free cloth.

ANNEX

Technical Specifications

Dimensions	162.6 x 76 x 13.6mm
Weight	265g
Display	5.7" 720x1440 with tempered glass protection. Usable with gloves and wet fingers.
System on Chip	Octa-core Cortex A53 2.0GHz, Mediatek Helio P22
RAM	4GB DDR4
Storage	64GB
OS	Android 11 with GMS
Cameras	Front: 5MP Back: 13MP with flash
Wifi	Wifi5 802.11a/b/g/n/r/ac
Bluetooth	Bluetooth 5.0 + BR/EDR + BLE
Modem	GSM: 850/900/1800/1900 WCDMA: B1/B2/B4/B5/B8 TD LTE: B34/B38/B39/B40/B41 FDD LTE: B1/B3/B5/B7/B8/B20/B28A/B28B
NFC	NFC ISO15693, ISO14443 A/B, Mifare, Felica
GPS	Embedded GPS
I/O	1x USB Type C 1x Headset jack 1x charging POGO port 1x options POGO port 1x SD card slot 2x Nano SIM slots
Keys	1x Power button 2x Volume 1x PTT 2x barcode scan
Barcode Scanner	Linear: Codabar, Code 11, Code 128, Code 2 of 5, Code 39, Code 93and 93i, EAN/JAN-13, EAN/JAN 8, IATA Code 2 of 5, Interleaved 2 of 5, Matrix 2of 5, MSI, GS1 Databar, UPC-A, UPC E, UPC-A/EAN-13with Extended Coupon Code, Coupon GS1 Code 32(PARAF), EAN-UCCEmulation, GS1 Data Bar2D Stacked: Codablock A, Codablock F, PDF417, MicroPDF4172D Matrix: Aztec Code, Data Matrix, MaxiCode, QR Code, Chinese Sensible

	(HanXin), Grid Matrix, Dot CodePostal: Australian Post, British Post, Canadian Post, China Post,Japanese Post, Korea Post, Netherlands Post, Planet Code, Postnet
Battery	Tool free replaceable battery 4300mAh, 3.85V (6000mAh option available)
Sensors	Proximity sensor Gravity sensor Light sensor Compass
Operating temperature	-20°C to 50°C
Storage temperature	-40°C à 70°C
Water and dust resistance	IP67

Note: specifications may change depending on your configuration

This product is built in People's Republic of China for Logic Instrument, 12 rue Ampère, 91430 Igny, FRANCE.

www.logic-instrument.com



Statements of Compliance

English This product follows the provisions of the European Directive 2014/53/EU.

French Ce produit respecte les dispositions de la directive européenne 2014/53/EU.

German Dieses Produkt entspricht den Bestimmungen der Europäischen Richtlinie 2014/53/EU.

Danish Dette produkt følger bestemmelserne i det europæiske direktiv 2014/53/EU.

Dutch Dit product voldoet aan de bepalingen van de Europese Richtlijn 2014/53/EU.

Finnish Tämä tuote noudattaa EU-direktiivin 2014/53/EU määräyksiä.

Greek Αυτό το προϊόν ακολουθεί τις διατάξεις της Ευρωπαϊκής Οδηγίας 2014/53/ΕΕ.

Icelandic Þessi vara fylgir ákvæðum Evróputilskipunar 2014/53/ESB.

Italian Questo prodotto segue le disposizioni della Direttiva Europea 2014/53/UE.

Norwegian Dette produktet følger bestemmelsene i det europeiske direktivet 2014/53/EU.

Portuguese Este produto segue as disposições da Diretiva Europeia 2014/53/UE.

Spanish Este producto sigue las disposiciones de la Directiva Europea 2014/53/UE.

Swedish Denna produkt följer bestämmelserna i det europeiska direktivet 2014/53/EU.

Emission Information

Technology	Frequency	Max EIRP
Bluetooth BDE+EDR	2402~2480	4.95 dBm
Bluetooth BLE	2402~2480	0.53 dBm
WLAN 2.4G	2412~2472	17.57 dBm
RLAN 5.1G	5150~5725	18.27 dBm
RLAN 5.8G	5725~5850	12.70 dBm

SAR

Frequency Band	Highest 10g SAR (W/kg) Body (0mm)
WIFI 2.4G ANT1	1.387W/kg
WIFI 2.4G ANT2	1.429W/kg
WIFI 5.1G ANT1	1.433W/kg

EU Declaration of Conformity

In accordance with EU Directives and Regulations

LOGIC INSTRUMENT

12, rue Ampere, 91430 Igny, France

as the manufacturer hereby declares under our sole responsibility that,

Product: 5.7" Rugged Handheld Terminal

Model name: Fieldbook F57G2, F57G2, DT50

is in conformity with the essential requirements of the Directive 2014/53/EU:

Article 3.1(a)	EN 62368-1:2014+A11:2017
Health & Safety	EN 50360 2017
	EN 50566 2017
	EN 50663 2017
	EN 62209-1:2016
	EN 62209-2:2010
Article 3.1(b)	EN 301 489-1 V2.2.3
Electromagnetic	EN 301 489-3 V2.2.0
Compatibility	EN 301 489-17 V3.2.4
	EN 301 489-19 V2.2.0
	EN 301 489-52 V1.2.1
Article 3.1(a)	EN 301 511 V12.5.1
Effective Use	EN 301 908-1 V15.1.1
Of Spectrum	EN 301 908-2 V13.1.1
	EN 301 908-13 V13.1.1
	EN 303 413 V1.1.1
	EN 300 328 V2.2.2
	EN 300 330 V2.1.1
	EN 301 893 V2.1.1
	EN 300 440 V2.1.1

An EU Type Examination Certificate for this Product was issued in accordance with the essential requirements of the 2014/53/EU by MICOM Labs Inc., Notified Body Identification Number 2280.

Signed on behalf of LOGIC INSTRUMENT.

(Signature of authorized person)

Name: Michel AFONSO

Title: Quality Manager

Date: 2022-08-03

